

www.chargebig.com





## Simple commissioning

No installation is necessary for the mobile system. A 63A supply cable simply needs to be connected to the bottom of the housing.

## Billing in compliance with calibration law

The charging points can be billed individually. Comprehensive reports on the charging processes are available in the chargeBIG dashboard.

## **Emergency procedure**

Residual current protection devices 30 mA FI type A and 6 mA RDC-MD for each charging point via reset button.

## Are you interested?

Please contact us and we will be happy to advise you on your mobile charging system.



www.chargebig.com